

Cabinets are pre-punched to accommodate the overhead mounting tray hardware. The Overhead Tray Corner Bracket distributes the weight of the overhead cable ladder across the cabinet frame



| CORNER BRACKET | STYLE  |
|----------------|--------|
| DPX-OV-BRKT-S  | SINGLE |
| DPX-OV-BRKT-D  | DOUBLE |

| FLIP-UP DOOR   | WIDTH |
|----------------|-------|
| DPX-OV-HD30-12 | 31"   |
| DPX-OV-HD26-12 | 26"   |
| DPX-OV-HD24-12 | 24"   |



Riser Rods attach to the corner bracket and support the overhead cable ladder above the cabinet. Riser Rods can also be used to support the External Riser Channel above the cabinet. The external riser channel can be used in conjunction with the Flip-Up Door as shown below.

The riser channel extends over 2 cabinets. Decommissioned cabinets can be pulled out of the row leaving the overhead tray in place. Use a single style riser at the end of a row of cabinets.

| RISER CHANNEL      | CABINET DEPTH | STYLE  | RISER RODS |
|--------------------|---------------|--------|------------|
| DPX-OVH-BAR-30S    | 30"           | SINGLE | 1 ½"       |
| DPX-OVH-BAR-34S    | 34"           | SINGLE | 1 ½"       |
| DPX-OVH-BAR-40S    | 40"           | SINGLE | 1 ½"       |
| DPX-OVH-BAR-30S    | 30"           | DOUBLE | 1 ½"       |
| DPX-OVH-BAR-34S    | 34"           | DOUBLE | 1 ½"       |
| DPX-OVH-BAR-40S    | 40"           | DOUBLE | 1 ½"       |
| DPX-OVH-BAR-30S-R1 | 30"           | SINGLE | 12"        |
| DPX-OVH-BAR-34S-R1 | 34"           | SINGLE | 12"        |
| DPX-OVH-BAR-40S-R1 | 40"           | SINGLE | 12"        |
| DPX-OVH-BAR-30D-R1 | 30"           | DOUBLE | 12"        |
| DPX-OVH-BAR-34D-R1 | 34"           | DOUBLE | 12"        |
| DPX-OVH-BAR-40D-R1 | 40"           | DOUBLE | 12"        |

